

FIT CHART			
MAKE	YEAR	BED LENGTH	PART NO.
Ford	1998 and older	6' and 8' Bed	DK2UKPD
Ford Superduty	1999–2016	6' or 8' Bed	DK2UFKPD
Ford	1997+	F150 new body	Not available
Dodge	1983 and older	6' and 8' Bed	DK2UKPD
Dodge	1984–1993	6' and 8' Bed	DK2UDKPD
Dodge	1994–2002	6' and 8' Bed	DK2UDNKPDP
Dodge	2003 and newer		Not available ¹
Chevy/GMC	1987 and older	6' and 8' Bed	DK2UKPD
Chevy/GMC	1988–1998	8' Bed	DK2UCKPD ^{2,3}
Chevy/GMC	1988–1998	6' Bed	DK2UCSBKPD ²
Chevy/GMC	1999–2017	8' Bed	DK2UCLB99KPD ³
Chevy/GMC	1999–2017	6' Bed	DK2UCSB99KPD ³

PIERCE®

PULLING FOR YOU

PIERCE STOCK BED DUMP KIT

FIT CHART NOTES:

- 1 Kit not available unless you have a channel crossmember
- 2 True '88–'98 trucks have a main frame crossmember that opens up. Some GM '88–'90 models require the DK2UKPD due to their downward facing crossmember.
- 3 True '99 trucks have a 3" round crossmember. Some GM '99–'01 models require the DK2UCKPD (long beds) or DK2UCSBKPD (short beds) due to their upward facing crossmember.

*PIERCE Stock Bed Kits are not for use on aftermarket beds.
For aftermarket beds use our Light Duty or Medium Duty Kits.*

Pierce Arrow Inc. • 549 U.S. HWY 287 S. • Henrietta, Texas 76365 • 1-940-538-5643 • www.piercearrowinc.com