


# BUCHER PUMP

PM319 Bucher Pump

# PIERCE®




## PULLING FOR YOU

Pierce Arrow Inc. • [www.piercearrowinc.com](http://www.piercearrowinc.com) • 1-800-658-6301  
549 U.S. HWY 287 S. • Henrietta, Texas 76365



### CONTROL WIRING CHART

Connect the wires to the corresponding signs.

-  POWER (green)
-  DOWN (white)
-  UP (black)

CATEGORY

PUMP

PART NO.


PM31910, PM3195G,  
PM3196P

### PRODUCT DESCRIPTION

Bucher Pump

### CONTROLS WIRING DESCRIPTION

This chart depicts wiring from a Bucher PM319 pump to the Pierce CP271MTE remote. Also compatible with a P040MTE.



### HARNESS WIRING CHART

Connect the wires to the corresponding signs.

-  POSITIVE
-  NEGATIVE

### HARNESS WIRING DESCRIPTION

This chart depicts wiring from a Bucher PM319 pump to the battery using #4 Gauge Wiring.

NOTE: Place breaker as close to battery as install allows. Use #4 gauge cable for all connections.

**GROUND:** Use the 5/16-18" x 3/4" bolt on the left hand side of the pump labeled GND (left in relation to pump motor facing you). Wire the other end of the 4 gauge ground wire directly to the negative terminal on the battery.