

SIX FUNCTION WRECKER CONTROL WIRING

P0406

PIERCE[®]
PULLING FOR YOU
 Pierce Arrow Inc. • www.piercearrowinc.com • 1-800-658-6301
 549 U.S. HWY 287 S. • Henrietta, Texas 76365


CATEGORY	REMOTE
-----------------	--------

PART NO.	P0406
-----------------	-------

PRODUCT DESCRIPTION
Six Function Wrecker Control

WIRING DESCRIPTION
This diagram depicts standard wiring for the P0406 remote.
NOTE: Includes a 20' cord but no plug for wiring.

WIRING CHART
Connect the wires as shown in the diagram.
 OUT (red)
 IN (red/black)
 DOWN (white)
 UP (White/black)
 CLOSE (blue)
 OPEN (green)
 MASTER (orange, motor start)
 12V (black, power)



Back view



Front view