

PIERCE®

PULLING FOR YOU

OWNER'S MANUAL
3 PT BALESPIKE
ABS3PTLD



REGISTER YOUR PRODUCT!

We want to serve you.
Please register your product at
www.piercearrowinc.com/warranty/product-registration

Why register?

- product updates via email
- maintenance reminders via email
- quick technical service help if you encounter a problem

DISCLAIMER

The PIERCE 3 point bale spike and spears are not covered under any warranty against bending, breakage, or any other damage. Bale spikes and spears with the hay bale fully impaled on the spikes for the purpose of handling and transporting hay bales, have proven to be very reliable for their intended purpose.




Expected spike and spear failures have occurred when used improperly: if used to lift tractors, pull posts, transport more than one bale, lift a bale of hay on the bottom of the stack with hay bales stacked on top, used as rock pickers, or transporting bales that are not fully impaled on the spear and resting against the framework holding the spear.

SAFETY WARNING

Please be cautious of the following safety warnings:

- Always lift hay bale spear completely in bale and with bale firmly seated against 3 point hinge frame.
- Occasionally check to make sure bolts and pins are secure.

SPECIFICATIONS



BALE WEIGHT LIMIT

2,500 lbs.

SPEAR LENGTH

48" overall (44" usable)

HITCH TYPE

3 Point Hitch - Cat 1 & 2 (with provided bushings)


WARRANTY

2 years

PRODUCT WEIGHT

78 lbs.

COMPONENTS




LETTER	PART NO	DESCRIPTION
A	DHM16	lifting pins
B	ABS3PTLDHINGE	3 point hinge
C	ABS3PLDSB	stabilizer spears
D	ABS1SPEAR	48" forged spear

INSTALLATION BAG COMPONENTS

PART NO	QUANTITY	DESCRIPTION
15011	2	1/4" x 2" Grade 8 Bolt
PS559	4	1/4" Flat Washer
1137183	2	1/4" Grade 8 Locknut
DHM46	2	7/16" Keeper Pin
DHM16	2	Cat 1 Pin
DHM47	2	Cat 2 Bushings
ABS1SPBOLT	1	1/2" x 3" Bolt for Spear Collar

ASSEMBLY


STEP 1



Attach lifting pins (A) to designated lifting tabs facing outward, with provided pin, washers, and nut.


Optional: Install Cat 2 bushings if needed.

STEP 2



Insert stabilizer spears (C) to designated collars on 3 point hinge (B), and attach with 1/4 x 2" bolt, flat washer, and lock nut.

STEP 3



Insert Bale spear (D) into designated collar attaching with 1/2 x 3" bolt, flat washer, and Nut.

WARRANTY

Pierce Arrow Inc. warrants that the goods, equipment, and merchandise manufactured by Pierce Arrow Inc. are free from defects in material and workmanship. The warranty includes replacement or repair of defective mechanical parts for a period of two years from the date of shipment by Pierce Arrow Inc.

OBTAINING WARRANTY SERVICE

Pierce Arrow Inc. must be notified of any defect before repair or replacement may be granted. The merchandise must be delivered by the purchaser to Pierce Arrow Inc. in Henrietta, Texas at the purchaser's expense. Any repairs not made by Pierce Arrow Inc. are not covered by the limited warranty and are the responsibility of the purchaser.

Pierce Arrow Inc. reserves the right to repair or replace de-fective parts or products in its sole discretion. The cost of any repairs not covered by the warranty will be charged to the purchaser.

EXCLUSIONS

All PIERCE products are manufactured for a specific intended purpose. The Pierce Arrow Inc. limited warranty does not cover, and Pierce Arrow Inc. is not liable for, damage arising from any use other than the specific intended use of each product.

The Pierce Arrow Inc. warranty does not cover:

- Ongoing maintenance parts or repair due to normal wear and tear.
- Any change or defect due to accident, misuse or any use for which the equipment was not intended, improper or unauthorized repair, failure to provide regular maintenance, and deterioration due to weather or road conditions.

Purchasers should consult their owner's manual for safety, installation, operation, and maintenance guidelines.

The Pierce Arrow Inc. limited warranty does not cover purchaser's cost of labor, transportation, shipping damages, installation or removal costs, down time, loss of profit or goodwill, or any other special, incidental, indirect, or consequential damages, concerning or related to any product or part, whether based upon negligence, strict liability, breach of contract, breach of warranty, misrepresentation, or any other legal theory.

Merchandise manufactured by Pierce Arrow Inc. is not designed or intended for the movement of people and are not to be used in the operation of elevators or other improper uses. Any improper use of the product may void the warranty.

WARRANTY

OTHER MANUFACTURERS' WARRANTIES

Pierce Arrow Inc. makes no warranty, expressed or implied, to finished products manufactured or supplied by other manufacturers, and sold by Pierce Arrow Inc. to the purchaser, including but not limited to, any vehicle to which our product is affixed and any accessories. Such merchandise is subject to the manufacturer's warranty only, which will be provided upon request.

CONDITIONS OF SALE

When placing an order with Pierce Arrow Inc., the terms and conditions provided for payment, shipping, delivery and claims create an agreement between the purchaser and Pierce Arrow Inc. The agreement is to be performed in Clay County, Texas.

RETURNS: No returns are accepted without prior authorization. All items must be returned in their entirety. Please contact a sales representative for authorization. Upon authorization, returns must be shipped freight prepaid and may be subject to a 15% restocking fee. Please do not send returns COD. No returns will be accepted later than 30 days from the date of invoice.

DAMAGED GOODS: Pierce Arrow Inc. is not responsible for, and has no liability for:

- Damage arising during shipment
- Any change or defect due to accident, misuse or any use for which the equipment was not intended, improper or unauthorized repair, failure to provide regular maintenance, and deterioration due to weather or road conditions.

CLAIMS: Claims for breakage or damages during shipment must be made to the carrier at the time of delivery. If a signature is required, you must notify the driver and sign that there was damage. You must notify Pierce Arrow Inc. of the damage promptly so that a claim can be filed.



Thank you for choosing PIERCE!

We strive for 100% customer satisfaction.
We are committed to excellent customer service because we are *pulling for you*.

SHARE YOUR FEEDBACK

Are you 100% satisfied?

- **If YES:** Please write a review on Google at www.piercearrowinc.com
- **If NO:** Call us at 800-658-6301 or let us know how we can help at www.piercearrowinc.com/contact-us

LEARN MORE ABOUT PIERCE PRODUCTS

We'd be happy to send you any of our product line guides. Or call our team today with further questions. Check out our resource library to access PIERCE specification sheets, wiring diagrams, and manuals.

<https://www.piercearrowinc.com/documents/>

KEEP IN CONTACT

Pierce Arrow Inc.
549 US Highway 287 South
Henrietta, Texas 76365

Toll Free: (800) 658-6301
Local: (940) 538-5643
Fax: (940) 538-4382

www.piercearrowinc.com
www.youtube.com/piercearrowinc

Contact us – call, email, fax, telegraph, morse code.
Our sales team and technical service reps are ready and here to help you.

Open Monday – Friday 8 a.m. – 5 p.m. CST.

SHIPPING INFORMATION

All orders placed over the weekend will ship the following Monday unless it's a holiday.
Orders placed during holidays will ship when we return for work.