

# PIERCE

PULLING FOR YOU

## OWNER'S MANUAL BARBED WIRE UNROLLER ABWUR1



### REGISTER YOUR PRODUCT!

In order for us to best serve you,  
please register your product at  
[www.piercearrowinc.com/register](http://www.piercearrowinc.com/register).

#### *Why register?*

- receive product updates via email
- receive maintenance reminders via email
- receive quick technical service help if you encounter a problem

## SPECIFICATIONS

<b>Product Dimensions</b>	40.25" x 36.5" x 63"	<b>Application</b>	holds 1 to 2 rolls of wire
<b>Product Weight</b>	85 lbs	<b>Marathon Tires and Wheels</b>	15" x 6.5" - NHS, 4 ply max load, 30 psi wheels, 3" hub, 3/4" axle
<b>Warranty</b>	Limited Lifetime (against manufacturer's defects)		
<b>Material Type</b>	steel	<b>Max Capacity</b>	200 lbs

## SAFETY WARNINGS

- Not for highway use!
- Do not load unroller unless it is hitched to ATV/UTV.
- Do not use on steep inclines.
- Always make sure hairpin cotter pins are in place.
- Do not reverse once you start unrolling.
- Do not use excessive speed when pulling this trailer.
- The bottom roll of wire should unspool from the **bottom of the roll**.
- The top roll of wire should unspool from the **top of the roll**.

## INSTALLATION

- **Step 1:** Always make sure, before loading rolls of wire, that the trailer is properly secured to the ATV/UTV. This ensures that it will not become top heavy and tip over.
- **Step 2:** Remove the cotter pin from the rolling rod and remove from frame.
- **Step 3:** Insert the rolling rod through the roll of wire. Place back into slots on the frame and secure the cotter pin. The bottom roll of wire should unspool from the bottom of the roll.
- **Step 4:** Repeat step 3 for the second roll. The top roll of wire should unspool from the top.

## FAQ

**What are the relevant limits of the product? (i.e. capacity, how much weight can be applied?)**

2 rolls of wire

Max capacity: 200 lbs

**What kind of barbed wire is recommended?**

2 point barbed wire of all types

4 point barbed wire of all types

Slick wire (horse wire)

Any roll of wire that fits between 15¾"

## PIERCE ARROW PRODUCT LIMITED WARRANTY

Pierce Arrow Inc. warrants to the original purchaser only (whether a wholesale, OEM or retail customer) that the goods, equipment, and merchandise manufactured by Pierce Arrow are free from defects in material and workmanship. The Pierce Arrow limited warranty on parts covers such items for a period of one year on mechanical and electrical from the date of shipment by Pierce Arrow. All warranties cover only the product or product parts, and are nontransferable.

### OBTAINING WARRANTY SERVICE

Pierce Arrow must be notified promptly in writing, about the defect before any means of repair have been made. The merchandise must be delivered by the purchaser to Pierce Arrow in Henrietta, Texas at the purchaser's expense. Pierce Arrow reserves the right to repair or replace the merchandise proved to be defective. The purchaser is responsible for the cost of repairs made by Pierce Arrow if the repairs are not covered by the Pierce Arrow warranty.

### EXCLUSIONS

The Pierce Arrow warranty is not intended to cover normal maintenance parts, including but not limited to: wear pads, bushings, mud flaps, fender flares, light bulbs, oil filters and remote enclosures. Nor is the warranty intended to cover any change or defect due to accident; misuse; improper, inadequate or unauthorized repair; failure to provide maintenance or uses for which the equipment was not intended; and normal deterioration due to weather or road conditions. Reference the owner's manual for safety, installation, operation and maintenance guidelines.

The warranty does not bear the cost of labor, transportation, shipping damages, claimed down time, loss of profit or goodwill, or any other special, incidental, indirect, or consequential damages, concerning or related to any product or part, whether based upon negligence, strict liability, breach of contract, breach of warranty, misrepresentation, or any other legal theory.

Merchandise sold by Pierce Arrow, but not manufactured by it, is not warranted by Pierce Arrow and is subject to the manufacturer's warranty only. The manufacturer's warranty is available upon request.

Pierce Arrow makes no warranty, expressed or implied, to finished products manufactured or supplied by other manufacturers, and supplied from Pierce Arrow to the purchaser, including but not limited to, any vehicle to which our products is affixed to, and any accessories.

Merchandise manufactured by Pierce Arrow is not designed or intended for the movement of people and are not to be used in the operation of elevators or other improper uses. Any improper use of the product may void the warranty.

Please contact Pierce Arrow with any questions:

Pierce Arrow Inc.

549 U.S. Highway 287 S.

Henrietta, Texas 76365

(toll free) 800-658-6301

(o) 940-538-5643

(f) 940-538-4382

[www.piercearrowinc.com](http://www.piercearrowinc.com)

## ***Thank you for choosing Pierce!***

**We strive to offer 100% customer satisfaction on all our products. We are committed to excellent customer service because we are *pulling for you*.**

### **SHARE YOUR FEEDBACK**

*Are you 100% satisfied?*

- **If YES:** Please write a review on our Facebook page. [www.facebook.com/piercearrowinc](http://www.facebook.com/piercearrowinc)
- **If NO:** Call us at 800-658-6301 or let us know how we can help at [www.piercearrowinc.com/contact-us](http://www.piercearrowinc.com/contact-us)

### **STAY IN TOUCH**

Pierce Arrow Inc.  
549 US Highway 287 South  
Henrietta, Texas 76365

Toll Free: (800) 658-6301  
Local: (940) 538-5643  
Fax: (940) 538-4382

[www.piercearrowinc.com](http://www.piercearrowinc.com)  
[www.youtube.com/piercearrowinc](http://www.youtube.com/piercearrowinc)